



B R O M M E

# ASSEMBLY INSTRUCTIONS

Version 2.5



## MINI RACKING



B R O M E

1- Install side braces to the front and back posts using Carriage bolts 1/4 -20 x 1/2 and flange Lock nut 1/4 -20 .



2- Install Beams ( front and back ) by clipping to the bottom posts ..using Metal Screw 10/32 x 3/8 to secure in place.





B R O M E

3- Install Cross Beams as required at least the 1 down the middle using the Hardware included ( Carriage Bolt 1/4 –20 x 1/2 and Flange Nut 1/4 –20 ) . Additional cross beams can be added depending on end use.



4- Repeat steps 2 and 3 , for all levels required.

5- Repeat all steps as required for additional bays .



B R O M E

